## 2. Operation

## Console Overview - Bike and Elliptical



1	LED display	Bike and Elliptical: Speed, Time, Distance, Heart rate, Calories, Incline, Resistance.
2	GO	Press to automatically begin a Quick Start workout.
3	Call out button	Calories, Watts, RPM.
4	Workouts key	Manual, Hills, Random.
5	USB Port	Charge USB devices.
6	STOP	Press to Stop a workout.
7	UP and DOWN arrow keys	Use to increase / decrease speed.
8	Call out button	Time, Weight, Imperial/Metric.
9	Reading Rack / Tablet Holder	Place traditional reading material as well as mobile devices and tablets in this built-in holder.

## Setting the INC Life-Fitness Upright Bike up for the 12-minute Physical Readiness Test (PRT).

- Step 1. Using Item (4), select the first button on the left with this ( ) symbol. This is your **MANUAL** workout key.
- Step 2. Select Item (7) for **TIME**, use the up/down arrow to select time enter 14 minutes, machine will automatically go into cool-down mode 2 minutes prior to reaching 14 minutes. At 12 minutes the CFL must record the calories burned in 12 minutes. Indicator (8) will illuminate for time.
- Step 3. Select Item (7) to Increase or Decrease resistance **LEVEL**, use the up/down arrow to select resistance level.
- Step 4. Select Item (7) to adjust member's **WEIGHT**, use the up/down arrow to select weight for member. Indicator (8) will illuminate for weight.
- Step 5. Select Item (2) **GO** to start the PRT test.

Upon completion of the 12-minute PRT test the CFL/ACFL must record the number of calories burned during the 12-minute test and record on the official PRT score sheet.